





1. Open the top lid and cut off the rubber band.
2. Unscrew the black knob at the center of hanger. And lift up the hanger.
3. Take out the vinyl bags and flap the bags to make some space between bags like you do the paper sheets of copier for the correct printing without tangle on the copy machine. And then insert the hanger into aluminum pipe.



4. Move the hanger to the end of Aluminum pipe. Take off the aluminum pipe.
5. Fix the hanger into the post bolt at the centre and place 2 legs of hanger inside of 2 posts in front side. Keep all the vinyl bags at the rear of hanger, pull the front first vinyl bag forward and keep the front vinyl bag at the cross bars.
6. Screw the black knob on the centre of hanger and close the top lid.



www.EagleMat.com

P: (877) 333-1018

E: sales@eaglemat.com