

Installation Instructions

Stainless Steel Corner Guards

FIG. 1a






FIG. 1b



Please read all instructions before installing corner guards. Material must be stored, installed and used in environmentally controlled conditions.

1. The wall surface that the corner guards are to be applied must be dry and free of dirt, dust, oil, loose paint, wax and grease.
2. **CEMENT-ON INSTALLATION**
Apply a bead of PL Premium Heavy Duty Adhesive in a zig-zag pattern over the back of each wing of the corner guard. See Figure 1a. Position corner guard on the wall and apply pressure until a tight fit is achieved. Remove the protective plastic coating from the exposed surface of the corner guard.
See Figure 1b.
3. **SCREW-ON INSTALLATION**
Attach corner guard to wall with provided hardware. Remove the protective plastic coating from the exposed surface of the corner guard.
See Figure 2.

FIG. 2



932 Hungerford Dr. #37B
Rockville, MD 20850
1-877-333-1018

www.eaglemat.com